





Manual package for the PSS-Range



Separate Manuals for the PSS-Range



Manual package for the PSS-Range

The manual package consists of four manuals. Their component parts are described below.

System Manual

Safety Manual

Describes the safe application of the PSS. This will provide support when planning, installing, commissioning, decommissioning and dealing with potential problems.

FS System Description

Explains the function and operation of the safety-related (failsafe) section of the PSS. The FS System Description contains essential basic information that you will need when using the FS section of the PSS.

ST System Description

Explains the function and operation of the non-safety-related (standard) section of the PSS. The ST System Description contains essential basic information that you will need when using the ST section of the PSS.

Error List

Contains a list of all the error messages that can be displayed by the PSS, including a description of the error and advice on how to rectify it.

Installation Manual - Modular PSS

Product Changes

Describes the changes made when the version numbers changed on the different CPU modules and safety systems.

Installation Manual

Describes how to install and wire the PSS. Important advice is given on how to connect the modules' I/Os correctly and how to apply them in a way that conforms to the standards. The Installation Manual is also enclosed with the PSS(1) module rack.

Operating Manuals for the FS modules on the PSS(1)

Each FS module has an operating manual, which explains the structure of the module and the functions of its inputs and outputs.
The operating manual is also enclosed with the module.

Installation Manual - Compact PSS

Product Changes

Describes the changes made when the version numbers changed on the different CPU modules and safety systems.

Overviews of the compact PSS

Each compact PSS has a short overview, which explains the structure of the PSS and the functions of its inputs and outputs.
The overview is also enclosed with the PSS.

Installation Manuals for the compact PSS

Each compact PSS has an installation manual, which describes how to install and wire the PSS. Important advice is given on how to connect the I/Os correctly and how to apply them in a way that conforms to the standards. The Installation Manual is also enclosed with the PSS.

Programming Manual

Programming Manual

Explains the structure, creation and management of user programs for the PSS.

Programming Device

Explains how to use the system software to create user programs.

Overview

This contains all the most important information required to program a PSS, in an abbreviated format. Detailed descriptions of individual topics can be found in the Programming Manual.

Separate Manuals for the PSS-Range

Selective Shutdown

The “PSS Selective Shutdown” manual supplements the “PSS-Range System Manual” on PSS applications that use selective shutdown.

Safety Manual

Describes the safe application of the PSS with selective shutdown. This will provide support when planning, installing, commissioning, decommissioning and dealing with potential problems.

Operating Manual

Explains the functionality and features of the PSS with selective shutdown, and also covers configuration and programming.

Application Example

Shows how to use PSS selective shutdown on a tank farm installation and describes the procedure for configuration and programming. The example is intended to help you get started with PSS selective shutdown.

SafetyBUS p

The "SafetyBUS p" manual supplements the "PSS-Range System Manual" with information on the SafetyBUS p bus system.

System Description

Explains the function of SafetyBUS p, providing basic information and configuration / programming support.

Installation Manual

Describes how to install and wire the bus system.

The Installation Manual is also enclosed with the CPUs and compact PSS systems with SafetyBUS p connection.

Operating manuals for the decentralised modules

Each decentralised module manufactured by Pilz has an operating manual, which explains the structure of the module and the functions of its inputs and outputs. The operating manual is also enclosed with the module.

Installation manuals for the decentralised modules

Each decentralised module manufactured by Pilz has an Installation Manual, which explains how to install and wire the module. Important advice is given on how to connect the I/Os correctly and how to apply them in a way that conforms to the standards.

The Installation Manual is also enclosed with the CPUs and compact PSS systems with SafetyBUS p connection.

A Pilz Ges.m.b.H., ☎ (01) 7 98 62 63-0, Fax (01) 7 98 62 64 **AUS** Pilz Australia, ☎ (03) 95 44 63 00, Fax (03) 95 44 63 11 **B, L** Pilz Belgium, ☎ (0 53) 83 66 70, Fax (0 53) 83 89 58 **BR** Pilz do Brasil Sistemas Eletrônicos, ☎ (11) 55 05 86 67, Fax (11) 55 05 86 69 **CH** Pilz Industrieelektronik GmbH, ☎ (0 62) 8 89 79 30, Fax (0 62) 8 89 79 40 **DK** Pilz Skandinavien KS, ☎ 74 43 63 32, Fax 74 43 63 42 **E** Pilz Industrieelektronik S.L., ☎ (93) 8 49 74 33, Fax (93) 8 49 75 44 **F** Pilz France Electronic, ☎ 03 88 10 40 00, Fax 03 88 10 80 00 **FIN** Pilz Skandinavien KS, ☎ (09) 27 09 37 00, Fax (09) 27 09 37 09 **GB** Pilz Automation Technology, ☎ (0 15 36) 46 07 66, Fax (0 15 36) 46 08 66 **I** Pilz Italia srl, ☎ (0 31) 78 95 11, Fax (0 31) 78 95 55 **IRL** Pilz Ireland Industrial Automation, ☎ (0 21) 27 48 83, Fax (0 21) 27 48 94 **J** Pilz Japan Co., Ltd., ☎ (0 45) 4 71-22 81, Fax (0 45) 4 71-22 83 **MEX** Pilz de Mexico S. de R.L. de C.V., ☎ (0 13) 1 22 16 81, Fax (0 13) 6 47 81 85 **NL** Pilz Nederland, ☎ (03 47) 32 04 77, Fax (03 47) 32 04 85 **P** Pilz Industrieelektronik S.L., ☎ (01) 76 22-1 01, 1 03, Fax (01) 76 22-1 02 **PRC** Pilz China Representative Office, ☎ (0 20) 87 37 16 18, Fax (0 20) 87 37 35 55 **S** Pilz Skandinavien KS, ☎ (03 00) 1 39 90, Fax (03 00) 3 07 40 **SGP** Pilz Industrial Automation Pte Ltd., ☎ 5 62 94 84, Fax 5 62 94 85 **USA** Pilz LP, ☎ (2 48) 4 73-11 33, Fax (2 48) 4 73-39 97 **www** <http://www.pilz.com>

D Stammhaus/Headquarter/Maison mère: Pilz GmbH & Co., Felix-Wankel-Straße 2, D-73760 Ostfildern, ☎ (07 11) 34 09-0, Fax (07 11) 34 09-1 33, E-Mail: pilz.gmbh@pilz.de